

封面



封底

Dongguan Suoai Electronics CO.,LTD
www.aulagaming.com
SOAI Industry Park, Huayu Street Changlong
Village Huangliang Town Dongguan City
Guangdong Province
Execution Standard:GB/T 14081-2010
Made in China



USER MANUAL

Keyboard Function Description
Diagram of keyboard with numbered callouts 1-6: 1 Type-C interface, 2 Keyboard toggle switches, 3 USB receiver, 4 Individual indicator light, 5 PVC nameplate, 6 Mode switching knob.

1

Wired Mode/On/Off
1 Switch to [Wired] mode (FN+4S short press to enter wired mode = 4S button's light effect light colour)
2 Plug the Type-C cable end into the corresponding port of the keyboard
3 Plug the USB end of the cable into your computer's USB port

2

BT connection instructions
1 Switch to [BT] mode
2 Press the key combination to switch to BT1. Press and hold for about 5s until the light flashes into Pairing
3 Search for the pairing name [AULA-S98 3.0] or [AULA-S98 2.1] to connect successfully, 11 key of the light with the light effects

3

Bottom ambient lighting effect adjustment
FN + N M
Switch bottom light bar on/off
Switching the bottom light bar mode

4

Operating system mode switching
FN + Q Android
FN + W Windows
FN + E MAC
FN + R IOS

5

FN+W=Windows system (W key light flashes 3 times), F-zone single press function and F-zone FN combination function.
Table with columns: Key, Single Press, FN Combination, Key, Single Press, FN Combination, Key, Single Press, FN Combination.

6

FN+R=IOS system (R key light flashes 3 times), F zone single press function and F zone FN combination function.
Table with columns: Key, Single Press, FN Combination, Key, Single Press, FN Combination, Key, Single Press, FN Combination.

7

Current Status Indicator Description
Press and hold FN to view: Current connection mode (2.4G, Bluetooth, wired); Current Bluetooth channel (channel 1, 2, 3); Current system mode (Android, Win, Mac, IOS)

8

Charging instructions for use
The keyboard can be charged by connecting it to the computer via the equipped USB cable. The Fn key is always on display during charging. Full light off.

9

User manual
Triple mode mechanical keyboard
-Wired & 2.4G & BT
-Number of keys: 96
-Size: 406x137.9x45mm

10

Manual do usuário
Teclado mecânico em triplo modo
-Wired & 2.4G & BT
-Número de chaves: 96
-Tamanho: 406x137.9x45mm

11

Manuale d'uso
Tastiera meccanica a tripla modalità
-Cablato & 2.4G & BT
-Numero di chiavi: 96
-Dimensioni: 406x137.9x45mm

12

Руководство пользователя
Трёхрежимная механическая клавиатура
-Кабель и 2.4G & BT
-Количество клавиш: 96
-Размер: 406x137.9x45mm

13

ИНСТРУКЦИЯ ПО ПРИМЕНЕНИЮ
Показатель, проанализируйте инструкцию перед первым использованием.
Сначала выберите продукт AULA.

14

Manuel de l'utilisateur
Clavier mécanique à trois modes
-câble et 2.4G & bt
-nombre de clés: 96
-Taille: 406x137.9x45mm

15

Panduan pengguna
Papan kekunci mekanik mode tiga
-Kabel & 2.4G & BT
-Nomor kunci: 96
-Ukuran: 406x137.9x45mm

16

说明书技术要求:
1.成品尺寸:100x130mm
2.材质:120g铜版纸+打骑马钉
3.工艺:单黑双面印刷