

# F87 3-Mode Mechanical Keyboard-30s

## Quick Operation Guidelines



Light Brightness plus	Android	switch light effects
Light Brightness minus	Windows	FN+ESC long press for three seconds = restore default state, connected BT devices will not be cleared
Light speed down	MAC	Switching light effect modes (left Shift)
Light speed up	IOS	Side light mode switching(right Shift)

### BT Connection

Switch to [BT] mode

Long press the key combination "FN+1" for about 3 seconds, the "1" Key start fast flash cyan light, into the code pairing state

Search for the pairing name [AULA-F87 Pro 3.0] or [AULA-F87 Pro 5.0], the blue light will turn on for 2 seconds after the link is successful.

Note: BT2 and BT3 are connected in the same way as BT1. BT2 can be connected by pressing the combination key [FN+2@]. BT 3 can be connected by pressing the combination key [FN+3#];The blue light blinks slowly when BT is connected again.

### 2.4G Connection 1

Switch to [2.4G] mode

Remove the [USB Receiver] from the upper right corner slot of the keyboard.

Plug into your computer's USB port to use

### 2.4G Connection 2

Long press the key combination "FN+" for about 3 seconds, the "-" Key start fast flash cyan light

Remove the [USB Receiver] from the upper right corner slot of the keyboard.

Plug into your computer's USB port to use

### Wired Connection

Switch to [Wired] mode

2. Plug the TYPE-C connector of the standard USB cable into the corresponding port of the keyboard.

3. Plug the cable's USB port into your computer's USB port to use it.

For additional features, please refer to the product brochure.